



Samsung BlackJack Teardown

This shows an exploded view of the Samsung Blackjack, its parts, and the tools needed for the remaining guides.

Written By: Kristin Manna



INTRODUCTION

Use this guide to view all the components and parts.



TOOLS:

- [26 Bit Driver Kit](#) (1)
 - [Spudger](#) (1)
 - [Tweezers](#) (1)
-

Step 1 — Samsung BlackJack Teardown



- From top to bottom, left to right: battery, back cover, screw handle, PH00 screw bit, small tweezers, camera screen, antenna cover, antenna and speaker, volume dial, speaker, power button, volume button, back button, keypad cover, tweezers, spudger, logic board, back case, front case

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-09-22 08:51:42 PM.